

# **USB 3.0 to SATA 6G Cable**

## **User Manual**

**Ver. 1.00**

All brand names and trademarks are properties of their  
Respective owners.

---

## Features & Specifications


- Supports USB 3.0 SuperSpeed and USB 2.0
- Plug and Play, no driver installation
- Compliant to Universal Serial Bus 3.0 Specification, Revision 1.0
- Compliant to Universal Serial Bus Specification, Revision 2.0
- Compliant with Serial ATA Specification, Revision 3.0
- Bus bandwidth of Serial ATA up to 6Gbps
- Supports ATA/ATAPI Packet Command Set
- Support ATA/ATAPI LBA48 addressing mode
- Supports both SATA 2.5" and SATA 3.5" hard drives
- Supports SATA ATAPI Optical Drives
- LED to indicate drive power and activity

- 1 x User Manual

- 1 x Power Adapter (Optional)

Note: Contents may vary depending on country/market.

## Hardware Description



## System Requirements

- Windows® XP/Vista/7 (32/64 bit)
- Available USB 2.0/3.0 port (USB 3.0 recommended)

## Package Contents

- 1 x USB 3.0 to SATA 6G Cable

---

MN3000000063

Page 2

## Hardware Installation

1. Connect SATA data/power connector to 2.5" or 3.5" SATA device
2. Plug the power adapter into the power jack of the USB 3.0 to SATA 6G Cable.
3. Plug the USB 3.0 to SATA 6G cable into your computer's Superspeed USB 3.0 port.

---

MN3000000063

Page 3

## ***Driver Installation***

Windows will automatically detect and install the drivers for the USB 3.0 to SATA 6G Cable.

